The Java Manager utility can be used to perform a broadcasting search of Matrix and iPAC series product to find their IP address.  If user would like to use this utility to configure their IP address, please do as follow

1.  use guest to login Matrix then use "*su*" to change to root user
2.  ftp or copy the "*netcfg*" to /home directory of Matrix
3.  Run "*netcfg*" in background by "./netcfg &" or include this command in /etc/rc file

Once netcfg is running in the background, you can use Java Manager to configure Matrix IP address and Host name.  When you double click on the device, the network configuration window will appear.  Once complete the settings, click save to use the new settings.  A password windows will pop up to confirm the root user password.  Please enter the root user password (default setting is *root*) to save the new settings.